


Direct Launch Links

Clients can be opened with the Direct Launch Links in addition to using the Gateway Home page. These links can be used in any browser on the network and will launch the **.jnlp** files without a desktop shortcut.

To Open a Client with the Direct Launch Link

1. Go to the **Configure** section of the Gateway.
2. Select **System > Projects**, and you will see a list of your projects on the **Projects** page.
3. Click the **More** link to the far right of the row for the project you want to launch, and select **details**. You will see the **Project details for 'your_project_name'**, and the **Published** and **Staging** launch links.



4. Right-click on **Published/Windowed Mode**. If you are using Google Chrome, click **Keep** on the small dialog box that appears on the bottom-left of your window, then click on the **.jnlp** file to start the Client.

Project details for 'Facility 1'

Launch Links

Published


[Windowed Mode](#)

[Fullscreen Mode](#)


Staging

[Windowed Mode](#)

[Fullscreen Mode](#)



Other browsers should start running immediately or may ask you if you want to save/run



the .jnlp file. Select **'Run'** if prompted.

Passing Parameters to a Client

Client Tag values in Ignition clients can be set when the client launches. You can do this by adding parameters to the end of launch links. This allows parameters to be passed into the client either from a URL in a website, through sending a co-worker a link, or by updating the properties on a desktop shortcut.

Client Tags that are set by the client launcher should not contain spaces in the Tag names!

Using the Launch Link

The example below assume that you have two client tags in the root folder of your project, called "LaunchTag" and "LaunchTag2".

```
http://1.1.1.1:8088/main/system/launch/client/myterminal.jnlp?LaunchTag=AAA&LaunchTag2=ZZZ
```

Related Topics ...

- [Native Client Launchers](#)